


3.1101.612408.00000000

原材料 机乐堂 JR-ZS240 车载磁吸无线充支架-说明书

尺寸：60x80mm

材质：128g铜版纸 正反单色印刷 风琴折

JOYROOM



User Manual

Magnetic wireless car charger holder

Specifications

Model: JR-ZS240
Name: Magnetic wireless car charger holder
Color: Black
Material: ABS + PC
Input: 5V 2.4A 9V 2A 12V 1.5A
Output: 5W/7.5W/10W/15W (MAX)
Input port: Type-C
Applicable phone size: 4.5-6.7 inch


Description

Wireless charging sensing area

Universal ball joint


Nut


Air outlet clip




JOYROOM

Operation steps







Step 1:

Connect the air outlet clip to this product, put the universal ball joint into the nut first, and then insert it into the bolt on the back of the product.

Step 2:


Tighten the nut clockwise

Step 3:

Insert it in the air outlet, tighten the rotary knob clockwise.


Step 4:

Connect the Type-C charging cable in the package to connect the holder and the car charger.



Step 5:

Put the phone on the holder, it can be accurately absorb the phone by magnetic.



Warning

1. Do not dismantle it or refit this product by yourself.

2. Do not put this product in the humid environment.

3. Please do not charge the product near the heat source or around it.

4. Do not let water or other liquids flow into the interface of this product, otherwise it may cause damage to the product.

5. Do not install the wireless charger on the airbag cover or airbag deployment area.

6. Please remove the metal and magnetic protective case or card (such as bank card) from your device when charging it.

7. It is normal to generate heat when charging and will not affect the performance of the product. But if you feel that the phone or the product is overheated, please disconnect the power supply and charge it after cooling down.

8. Avoid using the bent or damaged USB cables please.

Warranty Card

Model: _____

Purchase Date: _____

Distributor: _____

Invoice Date: _____

Tel.: _____

Customer Name: _____

Zip code: _____

After-sales service instructions

Dear users, thank you very much for using our products. In order to protect your rights and interests, it is clear that distribution agents and companies should bear the responsibility of product maintenance, replacement and return. Please read the following items:
1. Product warranty card, is our products to provide free after-sales service during the warranty period of the necessary proof.
2. According to who sells who is responsible for the three guarantees principle, the product quality problem with (product guarantee card) contact with the dealer, by the dealer to provide the service to the customer, my company provides the service support to the dealer.
3. The company undertakes that if a quality problem occurs within seven days from the date of sale (the date is valid, the date of the bill shall prevail), the customer may choose to return the goods to replace the goods and maintain the warranty. Products beyond warranty quality problems enjoy life-long maintenance (each after-sales service points only charge for component materials), customers are requested to purchase with the dealer to fill in (product warranty card).
4. Below cases are not included in the warranty
(1) Exceed the service time
(2) Damage caused by failure to use, maintain or keep in accordance with the requirements of the instructions for the use of the product
(3) A person who is not responsible for warranty will remove and cause damage
(4) No warranty card
(5) (The warranty card) where the contents of the card are not in accordance with the physical object of the product or are altered
(6) Caused by force majeure
5. Our company all rights reserved.